

D060454	D	INNER LOWER STRUCTURE	SUSPE	NSION STRUCTURE	J O'DELL	1	20
1-4_20X1-5D_UNC_THREAD_INSERT	A	1/4-20 x 1.5D UNC THREAD INSERT	.	.	M BALDWIN	62	1
1-4_20X1D_UNC_THREAD_INSERT	A	1/4-20 x 1D UNC THREAD INSERT	.	.	M BALDWIN	16	2
1-4_20_UNC_2-00INCH_ROUND	J	1/4" 20 UNC X 2" CAP HEAD, SPHERICAL	TIP.	.	J O'DELL	48	3
1-4_20_UNC_NUT__	A	1/4 20 UNC NUT	.	.	I WILMUT	60	4
8-32X1-5D_UNC_THREAD_INSERT	A	8-32 x 1.5D UNC THREAD INSERT	.	.	M BALDWIN	36	5
8-32_UNC_0-625INCH	A	8-32 UNC X 0.625" CAP HEAD	.	.	.	80	6
D060434	G	OUTER FACE PLATE	LOWER	STRUCTURE	J O'DELL	2	7
D060446	C	ADJUSTABLE PAD ASSEMBLY	LONG	.	.	2	8
1-4_20_UNC_1-5INCH	J	1/4-20 UNC X 1.5" CAP HEAD	.	.	.	2	1
1-4_20_UNC_2-00INCH_ROUND	J	1/4" 20 UNC X 2" CAP HEAD, SPHERICAL	TIP.	.	J O'DELL	2	2
D060444	C	BASE BAR - LONG	(ADJU	STABLE STOP MECHANISM)	J O'DELL	1	3
D060445	B	BUSH	(ADJU	STABLE PAD ASSYS)	N JS/FEL	2	4
D060447	B	ADJUSTABLE PAD JAW	ADJUS	TABLE PAD ASSY (LONG)	N JS/FEL	1	5
D060448	C	PIN	(ADJU	STABLE PAD ASSYS)	N JS/FEL	2	6
D060449	B	ADJUSTABLE PAD	ADJUS	TABLE PAD ASSY (LONG)	N JS/FEL	1	7
D060450	B	SPACER # 4	(TEST	MASS ADJUSTER)	J O'DELL	2	8
D060446_SKEL	C	SKEL	.	.	.	1	9
D060455	B	LOWER STRUCTURE X-BRACE	LOWER	STRUCTURE	J O'DELL	2	9
D060457	C	ADJUSTABLE PAD ASSEMBLY SHORT	.	.	I WILMUT	2	10
1-4_20_UNC_1-5INCH	J	1/4-20 UNC X 1.5" CAP HEAD	.	.	.	2	1
1-4_20_UNC_2-00INCH_ROUND	J	1/4" 20 UNC X 2" CAP HEAD, SPHERICAL	TIP.	.	J O'DELL	2	2
D060445	B	BUSH	(ADJU	STABLE PAD ASSYS)	N JS/FEL	2	3
D060448	C	PIN	(ADJU	STABLE PAD ASSYS)	N JS/FEL	2	4
D060450	B	SPACER # 4	(TEST	MASS ADJUSTER)	J O'DELL	2	5
D060458	C	BASE BAR	(ADJU	STABLE STOP MECHANISM)	N JS/FEL	1	6
D060459	B	ADJUSTABLE PAD JAW	SHORT	.	N JS/FEL	1	7
D060460	B	ADJUSTABLE PAD	ADJUS	TABLE PAD ASSY (SHORT)	N JS/FEL	1	8
TD-1103-262_SKEL	A	.	.	.	.	1	9
D060461	C	PEN TEST MASS PAD	.	.	N JS/FEL	2	11
D060462	G	INNER FACE PLATE	LOWER	STRUCTURE	J O'DELL	2	12
D060475	D	EARTHQUAKE-STOP MOUNTS-LONG	LOWER	STRUCTURE	N JS/FEL	6	13
D060476	C	EARTHQUAKE-STOP MOUNTS-SHORT	LOWER	STRUCTURE	N JS/FEL	6	14
D060477	C	PENULTIMATE MASS LWR STOP MT 1	.	.	N JS/FEL	2	15
D060478	B	PENULTIMATE MASS LWR STOP MT 2	.	.	N JS/FEL	2	16
D060479	B	PEN RE MASS PAD	.	.	N JS/FEL	2	17
D060481	C	ROUND MASS FRONT STOP	.	.	N JS/FEL	16	18
D060544	A	EARTHQUAKE STOP ASSY	.	.	I WILMUT	36	19
D060545	A	EARTHQUAKE STOP ADJUSTER	MADE	FROM 1/4" 20 UNC X 2" CAP HEAD	I WILMUT	1	1
D060546	A	EARTHQUAKE STOP	(COMP	LIANT)	I WILMUT	1	2
D060547	A	EARTHQUAKE STOP MOUNT PLATE	.	.	I WILMUT	1	3
D060548	A	FUSED SILICA EARTHQUAKE STOP	.	.	I WILMUT	1	4
D070008	B	SPACING PLUG	LOWER	STRUCTURE	I WILMUT	8	20
D070540	D	UIM TC E'QUAKE STOP ASSY #1	.	.	I WILMUT	1	21
1-4_20X1-5D_UNC_THREAD_INSERT	A	1/4-20 x 1.5D UNC THREAD INSERT	.	.	M BALDWIN	3	1
1-4_20_UNC_2-00INCH_ROUND	J	1/4" 20 UNC X 2" CAP HEAD, SPHERICAL	TIP.	.	J O'DELL	3	2
8-32X1-5D_UNC_THREAD_INSERT	A	8-32 x 1.5D UNC THREAD INSERT	.	.	M BALDWIN	2	3
8-32_UNC_0-625INCH	A	8-32 UNC X 0.625" CAP HEAD	.	.	.	7	4
D060336	H	2MM CAM	OSEM	ADJUSTER	I WILMUT	2	5
D070545	C	TEST CHAIN UIM STOP	LEFT	HAND	I WILMUT	1	6
D070548	C	UIM MASS STOP	BOTH	CHAINS	I WILMUT	1	7
D070541	D	UIM RC E'QUAKE STOP ASSY #1	.	.	I WILMUT	1	22
1-4_20X1-5D_UNC_THREAD_INSERT	A	1/4-20 x 1.5D UNC THREAD INSERT	.	.	M BALDWIN	3	1
1-4_20_UNC_2-00INCH_ROUND	J	1/4" 20 UNC X 2" CAP HEAD, SPHERICAL	TIP.	.	J O'DELL	3	2
8-32X1-5D_UNC_THREAD_INSERT	A	8-32 x 1.5D UNC THREAD INSERT	.	.	M BALDWIN	2	3
8-32_UNC_0-625INCH	A	8-32 UNC X 0.625" CAP HEAD	.	.	.	7	4
D060336	H	2MM CAM	OSEM	ADJUSTER	I WILMUT	2	5

D070546	C	REACTION CHAIN UIM STOP	LEFT	HAND	I	WILMUT	1	6
D070548	C	UIM MASS STOP	BOTH	CHAINS	I	WILMUT	1	7
D070542	D	UIM RC E'QUAKE STOP ASSY #2	.		I	WILMUT	1	23
1-4_20X1-5D_UNC_THREAD_INSERT	A	1/4-20 x 1.5D UNC THREAD INSERT	.		M	BALDWIN	3	1
1-4_20_UNC_2-00INCH_ROUND	J	1/4" 20 UNC X 2" CAP HEAD, SPHERICAL TIP.			J	O'DELL	3	2
8-32X1-5D_UNC_THREAD_INSERT	A	8-32 x 1.5D UNC THREAD INSERT	.		M	BALDWIN	2	3
8-32_UNC_0-625INCH	A	8-32 UNC X 0.625" CAP HEAD	.		.		7	4
D060336	H	2MM CAM	OSEM	ADJUSTER	I	WILMUT	2	5
D070547	C	REACTION CHAIN UIM STOP	RIGHT	HAND	I	WILMUT	1	6
D070548	C	UIM MASS STOP	BOTH	CHAINS	I	WILMUT	1	7
D070543	D	UIM TC E'QUAKE STOP ASSY #2	.		I	WILMUT	1	24
1-4_20X1-5D_UNC_THREAD_INSERT	A	1/4-20 x 1.5D UNC THREAD INSERT	.		M	BALDWIN	5	1
1-4_20_UNC_2-00INCH_ROUND	J	1/4" 20 UNC X 2" CAP HEAD, SPHERICAL TIP.			J	O'DELL	3	2
8-32X1-5D_UNC_THREAD_INSERT	A	8-32 x 1.5D UNC THREAD INSERT	.		M	BALDWIN	2	3
8-32_UNC_0-625INCH	A	8-32 UNC X 0.625" CAP HEAD	.		.		7	4
D060336	H	2MM CAM	OSEM	ADJUSTER	I	WILMUT	2	5
D070544	D	TEST CHAIN UIM STOP	RIGHT	HAND	I	WILMUT	1	6
D070548	C	UIM MASS STOP	BOTH	CHAINS	I	WILMUT	1	7
D090438	A	RINGHEATER ATTACHMENT PIECE	QUAD	N-P TYPE LS	J	O'DELL	4	25