

INPUT/OUTPUT SUMMARY FOR AIR HANDLING UNIT AH-01 (TYP 4 SYSTEMS)

SYSTEM APPARATUS OR AREA POINT DESCRIPTION	INPUTS		OUTPUTS					SYSTEM FEATURES		GENERAL	SUPPLEMENTARY NOTES
	ANALOG		BINARY	DIGITAL	ANALOG	ALARMS	PROGRAMS				
	MEASURED	CALCULATED									
TEMPERATURE PRESSURE AIR FLOW LEVEL POSITION VIBRATIONS HUMIDITY AIR FLOW TIME EFFICIENCY NET BLEED TEMP	STATUS FILTER SMOKE FREEZE AIR FLOW METER	OFF-AUTO-ON OFF-HE-LO OFF-HE-HI OFF-CLOSE MAKE-SIGSE DAMPER POSITION LEVEL POSITION HUMIDITY HUMIDITY SOFT CONTROL	OFF-AUTO-ON OFF-HE-LO OFF-HE-HI OFF-CLOSE MAKE-SIGSE DAMPER POSITION LEVEL POSITION HUMIDITY HUMIDITY SOFT CONTROL	OFF-AUTO-ON OFF-HE-LO OFF-HE-HI OFF-CLOSE MAKE-SIGSE DAMPER POSITION LEVEL POSITION HUMIDITY HUMIDITY SOFT CONTROL	OFF-AUTO-ON OFF-HE-LO OFF-HE-HI OFF-CLOSE MAKE-SIGSE DAMPER POSITION LEVEL POSITION HUMIDITY HUMIDITY SOFT CONTROL	OFF-AUTO-ON OFF-HE-LO OFF-HE-HI OFF-CLOSE MAKE-SIGSE DAMPER POSITION LEVEL POSITION HUMIDITY HUMIDITY SOFT CONTROL	TIME SCHEDULING START/STOP OPTION INITIALTY OPTION PROGRAM CHG ALARM INSTRUCT MAINT RM COND	TIME SCHEDULING START/STOP OPTION INITIALTY OPTION PROGRAM CHG ALARM INSTRUCT MAINT RM COND			
OUTSIDE TEMPERATURE											
OUTSIDE RELATIVE HUMIDITY											
PREHEAT COIL, HC-14											
PREHEAT COIL, HC-15											
AIR FILTER AF-01 (TYP 2)											2 SENSORS
AIR FILTER AF-02 (TYP 2)											2 SENSORS
MIXING AIR DAMPER 01											
MIXING AIR DAMPER 02											
COOLING COIL CC-01											
COOLING COIL CC-02											
HUMIDIFIER HU-01											
HUMIDIFIER HU-02											
SUPPLY FAN SF-01											
SUPPLY FAN SF-02											
SUPPLY AIR TEMP (TYP 2)											
SUPPLY AIR RELATIVE HUMIDITY											
ROOM TEMPERATURE (TYPICAL 5 ZONES)											
SPACE AVERAGE RELATIVE HUMIDITY											
ZONE DUCT HEATER (VEA)											
ZONE DUCT HEATERS (TYPICAL 5 ZONES)											
SMOKE DETECTOR (SD-01)											
MIXING AIR TEMP											
MIXING AIR RELATIVE HUMIDITY											
AIR COMPRESSORS (TYP 2)											
TOILET EXHAUST FAN, EF-01											
AIR FLOW DIAGRAM											
HEPA FILTERS											
FLOOR PLANS											

INPUT/OUTPUT SUMMARY FOR WATER CHILLERS CH-01 & CH-02 (TYP 4 SYSTEMS)

SYSTEM APPARATUS OR AREA POINT DESCRIPTION	INPUTS		OUTPUTS					SYSTEM FEATURES		GENERAL	SUPPLEMENTARY NOTES
	ANALOG		BINARY	DIGITAL	ANALOG	ALARMS	PROGRAMS				
	MEASURED	CALCULATED									
TEMPERATURE PRESSURE AIR FLOW LEVEL POSITION VIBRATIONS HUMIDITY AIR FLOW TIME EFFICIENCY NET BLEED TEMP	STATUS FILTER SMOKE FREEZE AIR FLOW METER	OFF-AUTO-ON OFF-HE-LO OFF-HE-HI OFF-CLOSE MAKE-SIGSE DAMPER POSITION LEVEL POSITION HUMIDITY HUMIDITY SOFT CONTROL	OFF-AUTO-ON OFF-HE-LO OFF-HE-HI OFF-CLOSE MAKE-SIGSE DAMPER POSITION LEVEL POSITION HUMIDITY HUMIDITY SOFT CONTROL	OFF-AUTO-ON OFF-HE-LO OFF-HE-HI OFF-CLOSE MAKE-SIGSE DAMPER POSITION LEVEL POSITION HUMIDITY HUMIDITY SOFT CONTROL	OFF-AUTO-ON OFF-HE-LO OFF-HE-HI OFF-CLOSE MAKE-SIGSE DAMPER POSITION LEVEL POSITION HUMIDITY HUMIDITY SOFT CONTROL	OFF-AUTO-ON OFF-HE-LO OFF-HE-HI OFF-CLOSE MAKE-SIGSE DAMPER POSITION LEVEL POSITION HUMIDITY HUMIDITY SOFT CONTROL	OFF-AUTO-ON OFF-HE-LO OFF-HE-HI OFF-CLOSE MAKE-SIGSE DAMPER POSITION LEVEL POSITION HUMIDITY HUMIDITY SOFT CONTROL	TIME SCHEDULING START/STOP OPTION INITIALTY OPTION PROGRAM CHG ALARM INSTRUCT MAINT RM COND	TIME SCHEDULING START/STOP OPTION INITIALTY OPTION PROGRAM CHG ALARM INSTRUCT MAINT RM COND		
WATER CHILLER, CH-01											
WATER CHILLER, CH-02											
CHILLED WATER PUMP, WP-01											
CHILLED WATER PUMP, WP-02											
CHILLED WATER RETURN TEMP											
CHILLED WATER SUPPLY TEMP											
CHILLED WATER BOOSTER PUMP											PUMP BY VE CONTRACTOR
CHILLED WATER FLOW DIAGRAM											
FLOOR PLANS											

NOTES:

- FOR LEGEND, ABBREVIATIONS AND GENERAL NOTES SEE SHEETS WA-H-001 AND WA-H-002.
- SMOKE DETECTORS WILL BE HARD WIRED TO THE SUPPLY FANS SF-01 & SF-02 MOTOR STARTER TO STOP FANS WHEN SMOKE DETECTED IN THE RETURN AIR STREAM. ALSO SMOKE DETECTORS WILL BE SOFTWARE CONNECTED TO DDC CONTROL PANEL AND THE FACILITY CONTROL ROOM.
- CONTROL SYSTEM SHALL BE STAND ALONE TYPE AND CONNECTED TO THE MAIN CONTROL AND MONITORING SYSTEM AT THE FACILITY CONTROL ROOM IN THE CORNER STATION BUILDING.
- VACUUM EQUIPMENT ROOM WILL BE PROVIDED WITH FOUR TEMPERATURE SENSORS TO CONTROL THE RESPECTIVE DUCT HEATERS. SYSTEM MAY AVERAGE THE READING OF THE FOUR ROOM TEMPERATURE SENSORS OR SELECT ANY SENSOR TO CONTROL THE DUCT HEATER.

SEQUENCE OF OPERATION:

- CHILLED WATER PLANT:
  - UPON A SIGNAL FROM THE CENTRAL CONTROL SYSTEM THE PACKAGED CONTROLS PROVIDED WITH THE WATER CHILLER WILL PERFORM THE FOLLOWING:
    - THE LEAD CHILLED WATER PUMP (WP-01) WILL START TO ESTABLISH STEADY WATER FLOW THROUGH THE SYSTEM.
    - UPON PROOF OF ESTABLISHED WATER FLOW THE LEAD CHILLER (CH-01) WILL START TO MAINTAIN THE LEADING CHILLED WATER TEMPERATURE SETPOINT (42°F).
    - THE PACKAGED DDC CONTROLS ON THE WATER CHILLER WILL CYCLE THE REFRIGERATION COMPRESSORS IN SEQUENCE TO MATCH THE SYSTEM THERMAL LOAD.
    - WHEN THE THERMAL LOAD DROPS BELOW THE MINIMUM OPERATING CAPACITY OF THE WATER CHILLER, THE PACKAGED CONTROL WILL ACTIVATE THE HOT GAS BYPASS CYCLE.
    - PACKAGED CONTROLS WILL RUN SELF-DIAGNOSTICS TEST BEFORE STARTING THE REFRIGERATION COMPRESSORS TO PROVE THAT ALL OPERATING CONDITIONS ARE WITHIN THE NORMAL LIMITS.
    - PACKAGED CONTROLS WILL CONTINUOUSLY MONITOR THE CHILLER OPERATION AND REPORT ANY OPERATIONAL OR SAFETY ALARMS TO THE OPERATOR COMPUTER IN THE FACILITY CONTROL ROOM. PACKAGED CONTROLS WILL AUTOMATICALLY STOP THE MALFUNCTIONING WATER CHILLER AND START THE STANDBY CHILLER.
    - CENTRAL CONTROL SYSTEM WILL ALTERNATE THE LEAD AND STANDBY WATER CHILLERS TO MAINTAIN EQUAL OPERATING PERIODS ON BOTH WATER CHILLERS.

- AIR HANDLING SYSTEM:
  - UPON A SIGNAL FROM THE CENTRAL CONTROL SYSTEM THE LEAD SUPPLY AIR FAN (SF-01) WILL START TO ESTABLISH A STEADY AIR FLOW THROUGH THE SYSTEM. THE DDC CONTROLS WILL PERFORM THE FOLLOWING:
    - MODULATE THE CONTROLLABLE PITCH VANES ON THE SUPPLY AIR FANS TO MAINTAIN THE DESIRED CONSTANT AIR VOLUME FLOW RATE REGARDLESS OF THE SYSTEM STATIC PRESSURE.
    - THE TEMPERATURE SENSORS LOCATED DOWN STREAM OF THE OUTSIDE AIR PREHEAT COILS WILL BE USED TO CONTROL THE CAPACITY OF THE DUCT ELECTRIC HEATERS TO MAINTAIN THE OUTSIDE AIR DRY BULB TEMPERATURE AT 30°F.
    - THE TEMPERATURE SENSOR LOCATED DOWN STREAM OF THE COOLING COIL WILL BE USED TO MAINTAIN THE LEAVING AIR DRY BULB TEMPERATURE AT THE SET POINT (55°F).
    - THE DDC CONTROLS WILL COMPARE THE SPACE ROOM TEMPERATURE SENSORS AND MODULATE THE FACE AND BYPASS DAMPER BASED ON THE MOST DEMANDING ZONE.
    - THE ROOM TEMPERATURE SENSORS (TYPICAL 4) OF VACUUM EQUIPMENT AREA SHALL BE USED TO MODULATE THE SCR CONTROLS ON THE RESPECTIVE ELECTRIC DUCT HEATER TO MAINTAIN THE ROOM TEMPERATURE SETPOINT (72°F).
    - THE ROOM TEMPERATURE SENSORS FOR OTHER ROOMS SHALL BE USED TO SEQUENCE THE CAPACITY CONTROL STAGES OF THEIR RESPECTIVE DUCT HEATERS TO MAINTAIN THE ROOM TEMPERATURE SET POINT.
    - WHEN THE ROOM TEMPERATURE RISES 5 DEGREES F ABOVE THE SETPOINT, THE CONTROL SYSTEM SHALL REPORT AN ALARM SIGNAL TO THE FACILITY CONTROL ROOM.
    - THE RELATIVE HUMIDITY SENSOR LOCATED IN VACUUM EQUIPMENT ROOM SHALL BE USED TO SEQUENCE THE CAPACITY CONTROL STAGES OF THE ELECTRIC HUMIDIFIER TO MAINTAIN THE SPACE MINIMUM RELATIVE HUMIDITY SETPOINT (30% RH).
    - THE SMOKE DUCT DETECTOR IN THE RETURN AIR DUCTS SHALL STOP THE SUPPLY AIR FANS WHEN SMOKE IS DETECTED IN THE RETURN AIR STREAM AND REPORT AN ALARM SIGNAL (AUDIO AND VISUAL) AT THE FACILITY CONTROL ROOM AND LOCAL CONTROL PANEL. THE SPACE DIFFERENTIAL PRESSURE SENSORS SHALL BE USED TO MODULATE THE MOTORIZED CONTROL DAMPERS ON THE RETURN AIR DUCTS AND THE OUTSIDE AIR DUCTS TO MAINTAIN THE SPACE PRESSURIZATION AT THE SETPOINT.

- EQUIPMENT START UP:
  - ALL WATER CHILLER SHALL BE SOFT START
  - THE SUPPLY AIR FANS SF-01 & SF-02 SHALL START AT THE MINIMUM STATIC PRESSURE AND GRADUALLY INCREASE THE SYSTEM STATIC PRESSURE TO MAINTAIN THE DESIRED AIR FLOW RATE.
  - THE BUILDING PRESSURIZATION SENSORS FOR VEA AND OSG (LAB AREA) SHALL MODULATE THE MOTORIZED DAMPERS LOCATED ON THE RETURN AIR & OUTSIDE AIR DAMPERS TO START AT LOSS RETURN AIR AND GRADUALLY MODULATE THE DAMPERS TO MAINTAIN THE BUILDING PRESSURIZATION SETPOINT.
- TOILET EXHAUST FAN:
  - THE TOILET EXHAUST FAN WILL RUN CONTINUOUSLY.

This document and the design it covers are the property of PARSONS. They are loaned only with the borrower's expressed written agreement that they will not be reproduced, copied, loaned, exhibited, or used in any other way, except by written consent from PARSONS to the borrower.

This document and the design it covers are the property of PARSONS. They are loaned only with the borrower's expressed written agreement that they will not be reproduced, copied, loaned, exhibited, or used in any other way, except by written consent from PARSONS to the borrower.

I:\Ligo\g04\h4\m\p031.rvt  
 DATE: 05/22/96  
 TIME: 10:18:09  
 DESIGN FILE: I:\Ligo\g04\h4\m\p031.rvt

NO.	DATE	BY	CHKD	ENGR	PROJ	DESCRIPTION
B	5-22-96	CLP	TTG	AA	Tom	BID ADDENDUM #2
A	4-19-96	CLP	ME	AA	TOM	FINAL DESIGN REVIEW & BID

DRAWN: CLP  
 CHECKED: ENGINEER  
 PROJ:



LASER INTERFEROMETER GRAVITATIONAL-WAVE OBSERVATORY SITE NO. 1 - HANFORD, WASHINGTON  
 TITLE: HVAC MID & END STATIONS SEQUENCES OF OPERATION & I/O SUMMARY SHEET  
 SCALE: NONE  
 PROJECT NUMBER: PP150969  
 SHEET NUMBER: 8094  
**WA-H-231**