



DO WE PROVIDE CABLE TRAYS THAT RING AROUND THE BSC CHAMBERS? OR JUST PASS BY (LIKE RAILS) ON EITHER SIDE OF THE CHAMBER?



SECTION A-A

LIFT SPLIT (TWO-PIECE) SPOOLS AT TOP CENTER, REMOVE SPOOLS LATERALLY (HORIZONTALLY), THEN UP [NEEDED FOR PRC & SRC INITIAL ALIGNMENT]

SPOOL BETWEEN BSC1 AND BSC2 CAN ONLY BE REMOVED BY LIFTING VERTICALLY
[NEEDED FOR BS OPTIC INITIAL ALIGNMENT]





THE SPOOL BETWEEN BSC3 AND BSC2 IS NOT REMOVABLE (LOCKED IN BY BSC2 CROSSBEAM AND SEI PIERS)