

LASER INTERFEROMETER GRAVITATIONAL WAVE OBSERVATORY
-LIGO-
CALIFORNIA INSTITUTE OF TECHNOLOGY
MASSACHUSETTS INSTITUTE OF TECHNOLOGY

Procedure	LIGO-E1200453-V2	7/May/2012
Fine Initial Alignment Procedure of the Transmission Monitor Telescope		
Keita Kawabe, Mattew Evans, Bram Slagmolen		

LIGO Hanford Observatory
PO Box 159
Richland, WA 99352-0159
Phone (509) 372-8191
Fax (509) 372-8137
E-mail: info@ligo-wa.caltech.edu

LIGO Livingston Observatory
19100 LIGO Lane
Livingston, LA 70754
Phone (225) 686-3100
Fax (225) 686-7189
E-mail: info@ligo-la.caltech.edu

California Institute of Technology
LIGO Project – MS 51-33
1200 E California Blvd
Pasadena CA 91125
Phone (626) 395-2129
Fax (626) 304-9834
E-mail: info@ligo.caltech.edu

Massachusetts Institute of Technology
LIGO Project – NW22-295
Cambridge, MA 01239
Phone (617) 253-4824
Fax (617) 253-7014
E-mail: info@ligo.mit.edu

1. References

1. “SOP for Arm Length Stabilization Setup in LVEA and VEA”, [M1100040v6](#).

2. Tools Required

- One laser sensor card to be used inside the chamber. The card should be wiped thoroughly clean and the part where the worker holds should be wrapped with aluminum foil. Make sure to double fold the foil edge so no aluminum shedding falls inside the chamber.
- One laser sensor card to be used outside the chamber.
- One green laser pointer for misc. work.
- Assortment of class B Allen keys.
- An iris on a small post and post holder.

3. Check Before Starting

- Rough initial alignment of the TMS to the ETM should have been done by IAS group outside of the chamber under the test end.
- Fine initial alignment of the ETM should have been done by IAS inside the chamber.
- TMS suspension system should be working, i.e. the TMS should be freely hanging with OSEM damping, and the OSEMs should react to various offsets.
- ISC frontend should be working, i.e. green QPDs on the TMS ISC table should be connected to the ADCs, h2iscey should be monitoring these QPDs and MEDM screen should be available for this.
- All the tools should be available.

4. Man power needed

This is a four-persons' job.

- One person to work inside the chamber.
- One person to work as a support outside of the chamber.
- One person to work on the ALS table.
- One person to work on the CDS workstation.

5. Procedure

1. Transition the VEA to laser hazard as per SOP.
2. Turn the laser on.
3. Remove the ALS table panel behind the green beam periscope.
4. Place the iris at a convenient place between the top periscope mirror and the partial mirror splitting the Hartman and the ISC beam path on the ALS table. Exact position doesn't matter, but it should be at a comfortable position for the worker to look at both sides.
5. Free and damp the TMS if it's not.
6. Completely remove the First Contact on ERM. **Ask SUS people for help.**
7. Confirm that the ETM and ERM are both free and damped.

8. Adjust the offset of the green QPDs so the output of all four quadrants become zero when no beam is hitting the QPD.
9. Inject the green beam into the chamber via the West viewport on the South door.
10. Adjust the periscope mirror on the ALS table so the beam hits the center of the first steering mirror in the green beam path on the TMS ISC table.
11. Look at the beam position on the viewport. Adjust the table position along the arm if the beam is about 1 inch above the center and centered horizontally.
12. Repeat the 10. and 11. until the beam is centered on the first steering mirror and roughly 1 inch above the center and centered horizontally on the viewport.
13. Steer the first steering mirror on the TMS ISC table until the beam hits both of the QPDs.
14. Try to exactly center the beam on two QPDs by slightly adjusting the beam position on the first steering mirror on TMS ISC table and realign. It might not be possible to do this easily, so give up if it takes too much effort.
15. At this point, the TMS beam should already be hitting the ETM. Observe how the beam is coming back from the ETM.
16. Move the TMS by adjusting the TMS SUS offset so the beam is roughly retro reflected by the ETM.
17. The above step changes the relative alignment of TMS in relation to the ALS table. Repeat steps 10 to 13 until the beam roughly retro is roughly retro reflected by the ETM while the QPDs are reasonably centered.
18. At this point, look at the iris. Repeat steps 12 to 16 until the retro reflected beam is centered in the iris.
19. Confirm that the beam is still roughly at the position specified in step 11. If not, you need to go back to step 10 and follow all the steps after that again.
20. At this point, the main beam path is in a good shape.
21. Look at the beam position on the top periscope mirror of HWS pick-off path on the TMS ISC table. It's OK if it's somewhat off-centered, but if it looks really bad (e.g. $\frac{1}{4}$ inches off from the center) you need to adjust the bottom periscope mirror on the TMS ISC table.
22. Adjust the top periscope mirror of the HWS pick-off path ON THE TMS ISC TABLE so the pick-off beam hits the center of the HWS top periscope mirror ON THE ALS TABLE.
23. Look at the HWS pick-off beam position on the viewport. If it's too far off from the center, adjust the top HWS periscope mirror position on the ALS table and repeat.
24. At this point, the HWS pick-off beam path is in a good shape.

LIGO E1200453-V2

Worker Name:

Date:

QPD1 values:

QPD2 values:

Main beam position on the viewport:

HWS pick-off beam position on the viewport: