LASER INTERFEROMETER GRAVITATIONAL WAVE OBSERVATORY

LIGO Laboratory / LIGO Scientific Collaboration

LIGO-E1200873-v1	Advanced LIGO	2 October 2012		
Test Procedure for Slow Controls Concentrator Auxiliary 4				
	Daniel Sigg			

Distribution of this document: LIGO Scientific Collaboration

This is an internal working note of the LIGO Laboratory.

California Institute of Technology LIGO Project – MS 18-34 1200 E. California Blvd. Pasadena, CA 91125

Phone (626) 395-2129 Fax (626) 304-9834 E-mail: info@ligo.caltech.edu

P.O. Box 1970
Richland WA 99352
Phone 509-372-8106

Fax 509-372-8137

Massachusetts Institute of Technology LIGO Project – NW22-295 185 Albany St Cambridge, MA 02139 Phone (617) 253-4824 Fax (617) 253-7014 E-mail: info@ligo.mit.edu

P.O. Box 940
Livingston, LA 70754
Phone 225-686-3100
Fax 225-686-7189

http://www.ligo.caltech.edu/

1 Overview

The slow controls concentrator auxiliary 4 supports 4 DC photodiode amplifiers, and 4 photodiodes interfaces.

2 Test Equipment

- Multimeter, scope and signal generator.
- Second slow controls concentrator auxiliary 4 (<u>D1201349 -v1</u>). Replace the 3 front-panel breakout boards with quad TNC breakouts.
- 2 test cables DB9 to 4xBNC (D1102414-v1).
- DC power supplies.

TP6 (+5V)_____

3 Documentation

• Schematics—D1201349 -v1

4 Tests

Power up the measurement equipment and open the lid of the DUT. Connect a DB37 cable (malemale) between the DUT and the second slow controls concentrator. Connect the test cables to "Photodiode DC 1-4 IN" and "Photodiode DC 1-4 OUT".

4.1 Power

Check the voltages on the concentrator power board. The voltage should be within 5% of nominal. Test that the OK signal is a TTL low (<0.8V).

TP8 (+15V)	
TP3 (-15V)	
TP9 (OK)	
4.2 LED	
Check that the LED on the fron	t panel and the 2 LEDs on the rear panel are lit.
Front panel LED	Rear panel LEDs

4.3 Testing

Apply a 1kHz sine wave to each the BNCs of the first test cable while measuring the response with a scope on the second test cable, at the front panel BNCs of the DUT (Photodiode Monitors) and at the front panel BNCs of the second concentrator (Photodiode Monitors).

	Pass/Fail				
Cable 1	Cable 2	DUT		2 nd concentrator	
		PDMon	PDMon+4	PDMon	PDMon+4
BNC 1					
BNC 2					
BNC 3					
BNC 4					

Move on of the test cables to the PD Amp DC 1-4 connector. Measure the voltage of the photodiode amplifier monitors at the DUT at the second chassis and at the rear cable (should be close to zero). The quad TNC breakouts of the second chassis have the connectors assigned as Gain 1 input, Gain 2 input, Monitor 1, Monitor 2, respectively.

Signal	Voltage at DUT	Voltage at 2 nd unit	Cable
Photodiode amplifier monitor 1			
Photodiode amplifier monitor 2			
Photodiode amplifier monitor 3			
Photodiode amplifier monitor 4			

Clip a $100 \text{ k}\Omega$ resistor to the TNC PD input of each DC photodiode amplifier channel in turn. Measure the voltage of the photodiode amplifier monitors at the DUT at the second chassis and at the rear cable. Make one measurement at this gain (voltage should be 100 mV).

Signal	Voltage at DUT	Voltage at 2 nd unit	Cable
Photodiode amplifier monitor 1			
Photodiode amplifier monitor 2			
Photodiode amplifier monitor 3			
Photodiode amplifier monitor 4			

Now ground the center pin of the corresponding gain input and measure again (should be 315mV).

Signal	Voltage at DUT	Voltage at 2 nd unit	Cable
Photodiode amplifier monitor 1			
Photodiode amplifier monitor 2			
Photodiode amplifier monitor 3			
Photodiode amplifier monitor 4			

Ground both the center pin and the outer shell to ground, measure again (should be 1.00V).

Signal	Voltage at DUT	Voltage at 2 nd unit	Cable
Photodiode amplifier monitor 1			
Photodiode amplifier monitor 2			
Photodiode amplifier monitor 3			
Photodiode amplifier monitor 4			

Ground the outer shell to ground, measure again (should be 3.15V).

Signal	Voltage at DUT	Voltage at 2 nd unit	Cable
Photodiode amplifier monitor 1			
Photodiode amplifier monitor 2			
Photodiode amplifier monitor 3			
Photodiode amplifier monitor 4			