



- NOTE:
1. PRE-TEST 1/2" PIPE WELDS PRIOR TO INSTALLING 2" JACKET. LEAK CHECK TO 1x10⁻¹⁰ NO DETECTABLE LEAK.
 2. KEEP 1/2" LINE CENTERED IN OUTER 2" JACKET.
 3. CLEAN PARTS IN WASH STATION PRIOR TO FINAL ASSEMBLY, AND BAG DURING STORAGE.
 4. USE CLEAN GLOVES WHEN HANDLING PARTS AFTER CLEANING.

PROPRIETARY AND CONFIDENTIAL
 THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION BELONGING TO PROCESS SYSTEMS INTERNATIONAL, INC. OR ITS AFFILIATED COMPANIES AND SHALL BE USED ONLY FOR THE PURPOSE FOR WHICH IT WAS SUPPLIED. IT SHALL NOT BE COPIED, REPRODUCED OR OTHERWISE FURNISHED IN WHOLE OR IN PART TO OTHERS EXCEPT IN ACCORDANCE WITH THE TERMS OF ANY AGREEMENT UNDER WHICH IT WAS SUPPLIED OR WITH THE PRIOR WRITTEN CONSENT OF PROCESS SYSTEMS INTERNATIONAL, INC. AND SHALL BE RETURNED UPON REQUEST.

DWG. NO.	DESCRIPTION	DWG. NO.	DESCRIPTION
V049-4-004	80K PUMP LINE, LEFT, GENERAL ARRANGEMENT		

REV	DESCRIPTION	CHKD	DRWN	DATE	DECN
0	ISSUED FOR FDR UPDATE	DWG	REF GS	1/10/96	0410

PROCESS SYSTEMS INTERNATIONAL, INC.
 20 WINDUP DR. WESTBOROUGH, MASSACHUSETTS 01581 USA

80K PUMP 2" JACKETED LINE
LIGD VACUUM EQUIPMENT

DWG NO: V049-4-161
 SHEET: 1 OF 1

LIGO-D970447-00-V