

LASER INTERFEROMETER GRAVITATIONAL WAVE OBSERVATORY
- LIGO -

CALIFORNIA INSTITUTE OF TECHNOLOGY
MASSACHUSETTS INSTITUTE OF TECHNOLOGY

Document Type	LIGO-T980072-00	D	8/27/98
COS IR Autocollimator Alignment System			
Michael Smith			

Distribution of this draft:

xyz

This is an internal working note
of the LIGO Project.

California Institute of Technology
LIGO Project - MS 51-33
Pasadena CA 91125
Phone (626) 395-2129
Fax (626) 304-9834
E-mail: info@ligo.caltech.edu

Massachusetts Institute of Technology
LIGO Project - MS 20B-145
Cambridge, MA 01239
Phone (617) 253-4824
Fax (617) 253-7014
E-mail: info@ligo.mit.edu

WWW: <http://www.ligo.caltech.edu/>

1 OVERVIEW

An IR alignment telescope/autocollimator will be used to establish the locations of the beam-dumps, baffles, PO mirrors, and PO telescopes in the IFO; and to align the optical axes of the PO telescopes. The autocollimator mode will be used for setting the COS alignment beam parallel to the IFO optical axis, and for aligning the optical axes of the PO telescopes. The alignment telescope mode will be used to project a focussed reticle alignment mark for centering the alignment beam, beam-dumps, baffles, PO mirrors, and PO telescopes.

2 COS ALIGNMENT BEAM

The IR autocollimator/alignment telescope will be placed on the SEI platform in HAM3 to provide an alignment beam for the 4K IFO, as shown in figure1. First the alignment telescope will be focussed to project an image of the reticle onto a target centered on the ITM_x .




Figure 1: Alignment Beams for COS, 4K IFO

Next the autocollimator will be focussed at infinity and adjusted in pointing angle so that the reflected reticle image is nulled, making the beam perpendicular to the ITM_x . Finally the tilt and displacement of the autocollimator will be iteratively adjusted until the alignment beam is both centered and perpendicular to the ITM_x .

The same procedure will be used in the 2K IFO. However, a periscope adapter will be required in HAM9 to get around the RM LOS structure, as shown in figure 2.




Figure 2: Alignment Beams for COS, 2K IFO

3 POSITIONING OF COS OPTICAL ELEMENTS

Ghost alignment beams will be generated by the wedge surfaces of each COC. Each COS optical element, e.g. the PO mirrors, beam-dumps, etc., will be positioned by focussing the alignment

telescope and projecting a ghost reticle onto a temporary target centered on each optical element; then by moving the element until the target is centered on the projected reticle. The alignment telescope has a sufficient focus range, and the beam remains centered with the mechanical axis over the entire focus range.

3.1. Preliminary Results

A preliminary test of the reticle projection technique was performed with the apparatus shown schematically in figure 3.




Figure 3: Apparatus to test the projected reticle technique

An image of the projection screen--containing a marked cross-hair, a calibrated machinists scale, and the green light projected image of the reticle from the alignment telescope--was captured with the CCD camera. The marks on the reticle are spaced 1 arc min, and the numbers on the scale indicate inches. The CCD camera image is shown in figure 4.

The observed resolution of the edges of the projected reticle was < 0.010 inch, which is equivalent to an angular resolution of $< 10 \times 10^{-6}$ rad. The resolution of the reticle image was limited by the pixilation of the CCD camera, which can easily be improved almost an order of magnitude simply by moving the camera closer to the screen. The diffraction limit of the 0.9 inch output aperture of the alignment telescope with 1060 nm light is approximately 10×10^{-8} rad. This implies that the limiting resolution of the reticle image is $< 1 \times 10^{-4}$ inch at the 26 m distance of the projection screen, and the pointing accuracy of autocollimator is limited to $< 10 \times 10^{-8}$ rad.

The experiment proved that the reticle projection technique can be used to align a target with a cross-hair to a fraction of a millimeter, and the autocollimator can be pointed to an accuracy of $< 1 \times 10^{-6}$ rad.




Figure 4: CCD image of the projection screen cross-hair with scale and projected reticle from the alignment telescope

4 ALIGNMENT OF PO TELESCOPES

The autocollimator mode will be used for the pre-alignment of the PO telescopes as well as for the final alignment and pointing on-site in the IFO.

4.1. Pre-alignment of PO Telescope

The prealignment of the PO telescopes will proceed in four steps.

4.1.1. Alignment of PO Telescope Housing

Step one is to remove the primary mirror with its mount and to set up the autocollimator perpendicular to the reference surface of the telescope housing by reflecting from the retro-mirror placed against the reference surface of the telescope, as shown in figure 5. Once this has been done, the telescope housing and the autocollimator will be locked down and will remain in fixed positions during the next two steps.




Figure 5: Step one, alignment of PO telescope housing

4.1.2. Alignment of Optical Axis of PO Telescope

The second step, as shown in figure 6, consists of installing the primary mirror, placing the small retro-mirror against the reference surface at the output aperture of the telescope, and adjusting the secondary mirror position to bring the output beam perpendicular to the retro-mirror with an approximately plane wavefront. The perpendicularity is determined by nulling the displacement of the return image of the reticle as seen through the autocollimator eyepiece. The flatness of the wavefront is determined by sharpening the focus of the return image with the secondary mirror as much as possible.




Figure 6: Step two, alignment of PO telescope optical axis

4.1.3. Centering of PO Telescope Output Aperture

After the optical axis has been established in step two above, the output flange will be mounted to the reference surface and the alignment telescope will project a focussed alignment cross hair

onto the target on the flange for centering with the optical axis of the PO telescope, as shown in figure 7.




Figure 7: Step three, centering of the output flange with the optical axis

4.1.4. Full Aperture Alignment of PO Telescope

For the final step four, as shown in figure 8, the autocollimator will be moved to the output side of the telescope so as to fill the aperture of the telescope. The barrel of the autocollimator will be inserted into the pre-aligned output flange, which is perpendicular and on-axis with the reference surface. The large retro-mirror will be independently aligned perpendicular the autocollimator. Then, while maintaining the alignment of the telescope by nulling the autocollimator, the secondary mirror will be fine-adjusted to achieve the best focussed image of the reticle as seen through the eyepiece of the autocollimator.




Figure 8: Step four, full aperture alignment of PO telescope

4.2. On-site Alignment of the PO Telescope in the IFO

The pre-aligned PO telescope will be centered on the alignment beam by focussing the alignment telescope and projecting a cross-hair onto the entrance aperture of the PO telescope. Subsequently, the PO telescope will be pointed along the axis of the alignment beam by using the auto-collimating mode. Refer to figures 1, and 2.

4.2.1. Centering Alignment

The center of the primary mirror will be aligned with the axis of the alignment beam by moving the primary gimbal mount until the temporary alignment target placed near the primary mirror is centered on the focussed projected cross-hair image. Next, the entrance-end of the PO telescope will be aligned similarly by moving it until the temporary alignment target placed at the entrance-end of the telescope housing is centered on the projected cross-hair image. Then the primary gimbal mount is locked in place in the middle of its pitch and yaw adjustment range. Any further tilting of the telescope will pivot about the center of the primary mirror, maintaining the centering within the clear aperture.

4.2.2. Pointing Alignment

The alignment beam will be focussed at infinity. A second alignment telescope with a pre-centered reticle will be inserted into the output flange of the PO telescope, and the front end of the PO telescope will be tilted in pitch and yaw until the projected cross-hair image is nulled with the reticle of the alignment telescope, as shown in figure 9. The PO telescope is now completely aligned with the reference beam.




Figure 9: On-site alignment of PO telescope in the IFO

5 ALIGNMENT TELESCOPE MOUNTING FLANGE

A conceptual drawing of the alignment telescope mounted in the flange at the back of the PO telescope is shown in figure 10. The inside barrel of the flange is perpendicular to the mounting surface, which is the optical reference surface for the PO telescope. The flange will be centered with the output beam of the PO telescope by using the projected reticle technique described previously.




Figure 10: Alignment telescope with IR CCD camera viewer