



as an alternate mounting method.

PLAN 'B : ADD (place) 1" witness optic: • 1 X 1" OPTIC (QTY. OF 1): Place with the Silicon witness wafer horizontally (HR side up) on top of the optics table. Indicated item on detail 'A' may be used as an alternate mounting method.

NOTE: AS A GENERAL RULE, PLACE WITNESSES JUST AFTER REMOVAL OF THE NEARES FIRST CONTACT. THEN REVMOE AS CLOSE TO THE NEXT CHAMBER OPENING.




PLAN B: ADD (place) 1" witness optic: • 1 X 1" OPTIC (QTY. OF 1): Place on its side, vertically as close to an optic as possible. Retain in place using a peek cable clamp as shown.



T1300014-v5 Aligo, BSC Flooring + HAM ISI, Witness Sample Placement Guidelines

HAM ISI: WITNESS WAFERS + WITNESS OPTIC PLACEMENT



PLAN B

DEFAULT

•

DEFAULT: ADD (place) Silicon Witness Wafer:

- using LIGO D1300275
 - adjacent to HxTS structure leg, away from beams.
- Refer to the layout of the particular chamber to determine best available location.


PLEASE NOTE (APPLICABLE TO SR3 AND PR3 ONLY): **1" WITNESS OPTIC SHOULD BE MOUNTED ON THE SIDE OF THE STRUCTURE** AND NOT ON THE FRONT FACE OF THE STRUCTURE AS SHOWN, FOR FEAR **OF RETRO-REFLECTION.**

D1300512


DEFAULT: ADD (place) 1" witness optic:


• 1 X 1" OPTIC (QTY. OF 1): Mount on HxTS structure using D1300512. Install vertically as close to an optic as possible. Retain in place using appropriate hardware





• VERTICALLY: 1 X 4" SILICON WAFER (QTY. OF 1): Place Witness silicon wafer vertically











BSC PLACEMENT OPTIONS (SEE Pg. 3 FOR PREFERRED MT. METHODS)

T1300014-v5 Aligo, BSC Flooring + HAM ISI, Witness Sample Placement Guidelines





THE NEXT CHAMBER OPENING.



T1300014-v5 Aligo, BSC Flooring + HAM ISI, Witness Sample Placement Guidelines



NOTE: AS A GENERAL RULE, PLACE WITNESSES JUST AFTER REMOVAL OF THE NEARES FIRST CONTACT. THEN REMOVE AS CLOSE TO

